



TROUSERS P295

EUROPEAN STANDARDS

EN 342:2017

Protective clothing – Ensembles and garments for protection against the cold (< - 5°C)

EN ISO 13688:2013

Protective clothing – General Requirements
EU Certificate of Conformity n° 001/2022*

*only when used with the jacket P392

PPE DESCRIPTION

- High rise back for kidney thermal protection
- Front zipper with protective flap and press studs
- Adjustable suspenders
- Leg zippers 57 cm long with protective flaps and press studs
- 1 back pocket
- 2 front pockets with thermal insulation
- Temperature is maintained in wet environments
- Resistant, breathable, easy maintenance

PACKAGING

Cardboard box

ALLERGIES

Anti-allergic finish, designed for human use

STORAGE INSTRUCTIONS

Store in a dry place. Protect against high temperatures and UV rays exposure. Once removed from the original packaging, it can be stored on a hang

TECHNICAL FILE

PERFORMANCE LEVELS

(Tested on a model size L)

Air Permeability

Thermal Insulation I_{cler}

Class 2 AP 58,1 mm / s
0,351 m² K/W (B)

Thermal Insulation	Light activity Exposure	Light activity Exposure	Moderate Activity Exposure	Moderate Activity Exposure
I_{cler} m ² / KM	8 hours ° C	1 hour ° C	8 hours ° C	1 hour ° C
0,351	- 6° C	- 23° C	- 24° C	- 42° C

PPE COMPOSITION

- Outer fabric 100% polyamide 6.6 185 gr/m²
- Lining 100% polyester 62 gr/m²
- Thermal Insulation 100% polyester 220 gr/m²

Colours

Navy, black, green, white, royal, bring green, red, orange, grey, chino, caramel, brown

Sizes

XXS – XXXL

USE INSTRUCTIONS

Keep the PPE closed when in use. Do not remove the conservation label must. Respect the label cleaning instructions. If not, it can shorten the life span of the PPE. The PPE must be kept in a good state of cleanliness and conversation. The PPE is permeable to water.

WASHING INSTRUCTIONS

Maximum washing temperature 40°C (normal cycle). Bleaching is not allowed. Do not machine dry. Do not iron. Do not dry clean.

